



PWT TREATED LVL VS PRESSURE TREATED LUMBER

PWT Treated LVL Features and Benefits

PWT Treated LVL used as a deck joist stays **FLAT** and **STRAIGHT**

- Your deck boards stay **FLAT** and **STRAIGHT** (reduce callbacks)

PWT Treated LVL has **no top or bottom**

- You do not need to “crown” your deck joists (labor savings)

Each piece of PWT Treated LVL is **consistent in size**

- You do not need to hand plane your deck joists to get a flat deck (labor savings)
- You can tape your joists on the ground before installation (labor savings)

PWT Treated LVL is **stronger than dimensional lumber**

- Longer spans eliminate mid-span beams and columns (material and labor savings)

PWT Treated LVL is a **dry treatment, not pressure treated**

- PWT Treated LVL is tighter than pressure-treated lumber (labor savings)

PWT Treated LVL comes with a **25-year warranty**

- Your deck substructure needs to last as long as your deck boards



Scan for AIA CE Credits

